TIGERIES.

MODEL: 70-138



INTRODUCTION

GIGA PETS ARE THE CUTEST PETS YET, AND NOW BARBIE HAS A GIGA OF HER VERY OWN: PRECIOUS KITTY! IT'S UP TO YOU AND BARBIE TO KEEP YOUR KITTY AS HEALTHY AND HAPPY AS IT CAN BE ARE YOU READY?

CONGRATULATIONS!

YOU ARE THE PROUD NEW OWNER OF A GIGA PET, THE TAKE-IT-ANYWHERE INTERACTIVE PET! YOUR NEW GIGA PET IS GOING TO NEED LOTS OF ATTENTION TO GROW UP HEALTHY AND HAPPY. THE HEALTHIER AND HAPPIER YOUR PET IS, THE HIGHER YOUR SCORE WILL BE! THESE INSTRUCTIONS WILL HELP YOU ON YOUR WAY.

STARTING THE GAME
TO START YOUR GAME, PULL THE PLASTIK TAB FROM THE BACK OF YOUR GIGA
PET. THE PLASTIK TAB IS NOT PART OF THE TOY AND SHOULD BE THROWN AWAY.
ONCE YOU TURN YOUR GIGA PET ON, IT SHOULD STAY ON. YOU NEVER NEED
TO TURN YOUR GIGA PET OFF.

SETTING THE CLOCK
IT IS VERY IMPORTANT THAT YOU SET THE CLOCK ON YOUR GIGA PET FOR
THE CORRECT TIME YOUR GIGA PET EATS, PLAYS, AND SLEEPS ACCORDING TO
A NATURAL SCHEDULE IF YOU DON'T SET THE TIME CORRECTLY, YOUR GIGA PET
MAY GET CONFUSED- YOU DON'T WANT YOUR PET TO SLEEP ALL DAY AND KEEP
YOU AWAKE ALL NIGHT! WHEN YOU FIRST START THE GAME, YOUR GIGA PET
WILL BE IN GLOCK MODE. HERPS HOW TO SET THE CLOCK:

- D THE ROUR WILL BE FLASHING. PRESS LEFT/RIGHT TO ADJUST THE HOUR. WHEN THE CORRECT HOUR IS SET, PRESS ENTER.

  2) THE MINUTES WILL BE FLASHING. PRESS LEFT/RIGHT TO ADJUST THE MINUTES. WHEN THE CORRECT MINUTES ARE SET, PRESS ENTER.

  3) THE CLOCK IS NOW SET, AND YOU WILL AUTOMATICALLY ENTER NAME MODE.

- NAMING YOUR GIGA PET

  D. A FLASHING BAR WILL APPEAR UNDER THE SPACE FOR EACH LETTER.

  2) PRESS LEFT/RIGHT TO SEARCH THROUGH THE ALPHABET.

  3) PRESS ENTER TO SELECT A LETTER AND MOVE TO THE NEXT SPACE IN THE PET'S MAME, YOU MAY USE UP TO 12 LETTERS.

  4) PRESS ENTER TWICE TO ACCEPT THE CURRENT NAME AND RETURN TO GAME

TURNING OFF THE SOUND

- D PRESS MODE TO ENTER CLOCK MODE.

  2) PRESS LEFT TO TURN THE SOUND OFF-- THE SOUND ICON A WILL
- 3) PRESS RIGHT TO TURN THE SOUND ON-- THE SOUND ICON 4 WILL PRESS MODE AGAIN TO RETURN TO GAME MODE

HAPPY BIRTHDAY!

WHEN YOU ENTER GAME MODE FOR THE RRST TIME, YOU WILL SEE THE ARRIVAL OF YOUR NEW GIGA PET! EVERY GIGA PET ARRIVES IN A DIFFERENT KIND OF WAY. PRECIOUS KITTY COMES TO YOU IN A LITTLE BASKET HOW CUTE!

RETURNING TO CLOCK MODE ONCE THE GAME BEGINS IN GAME MODE, YOU CAN RETURN TO CLOCK MODE BY PRESSING MODE UNTIL THE CLOCK APPEARS.

- U) IF YOU WISH TO ADJUST THE CLOCK WILL START FLASHING.

  2) AFTER YOU SET THE TIME, YOUR PET'S NAME WILL APPEAR. PRESS ENTER TO ADJUST THE NAME.
- 3) TO RETURN TO GAME MODE, PRESS MODE UNTIL YOUR PET APPEARS

THE GAME SCREEN
THE GAME SCREEN IS YOUR PET'S "HOME." YOU WILL SEE THE PET MOVE AROUND
THE SCREEN AND GO ABOUT ITS DAILY ROUTINE, JUST LIKE A REAL PET.

PRESS THE **LEFT/RIGHT** KEYS TO SELECT THE DIFFERENT **ICONS** AROUND THE OUTSIDE OF THE SCREEN. THESE KONS REPRESENT ALL OF THE DIFFERENT ACTIVITIES THAT ALLOW YOU TO INTERACT WITH YOUR PET.

JUST LIKE A REAL PET, YOUR **GITGA PET** NEEDS YOU IN ORDER TO GROW UP HAPPY AND HEALTHY. AT VARIOUS TIMES, YOUR PET WILL REQUIRE A CERTAIN KIND

OF ATTENTION FROM YOU. YOUR PET WILL MAKE NOISE AND THE ALERT KON ?! WILL LIGHT UP.

NOW YOU'E GOT TO RIGURE OUT WHAT YOUR PET NEEDS! IF YOUR PET IS HUNGRY, FEED IT. IF YOUR PET IS LONELY, PLAY WITH IT. IF YOUR PET IS DIRTY, GIVE IT A BATH. THERE ARE MANY DIFFERENT WAYS FOR YOU TO INTERACT WITH YOUR PET. THE TRICK IS TO RIGURE OUT WHAT YOUR PET NEEDS FROM YOU! USE THE LEFT REGIST KEYS TO MOVE TO THE ACTIVITY YOU WANT, AND PRESS ENTER. HERE ARE THE ACTIVITIES:



VALEN YOU SELECT THIS ACTIVITY, YOU WILL BE GIVEN A CHOKE OF FOODS FOR YOUR PET. USE THE LEFT OR PLEGIT KEY TO SELECT BTHER HEALTHY FOOD OR TREATS. EVERY KIND OF PET LIKES DIFFERENT KINDS OF FOOD. YOUR PRECEIOUS RETTY NEEDS A BOWL OF HEALTHY FOOD TO GROW. BUT IF YOUR KITTY IS VERY GOOD, YOU CAN FEED IT A TREAT-- A TASTY RSH NIBPLE!

YOU CAN SEE HOW HUNGRY YOUR PET IS BY CHECKING ITS NUNGER A ON THE SCORE SCREEN . A O MEANS YOUR PET HAS A FULL TURNAY-- AND A O MEANS YOUR PET IS FAMISHED! IF YOUR PET HAS A ON 100 IT MAY REFUSE TO EAT, AND IF IT HAS A O MAY REFUSE TO DO ANYTHING BLSE UNTIL YOU FEED IT!

YOUR PET WILL ALWAYS EAT TREATS, EVEN WHEN IT'S FULL! THOSE TREATS TASTE SO GOOD, IT'S IMPOSSIBLE TO SAY NO! BUT BE CAREFUL, TOO MANY TREATS WILL MAKE YOUR KITTY FAT,



SLEEP W SELECT THIS KON TO TURN OUT THE LIGHT WHEN YOUR PET WANTS TO SLEEP. YOUR PET LIKES TO TAKE NAPS DURING THE DAY. IF YOU TURN OUT THE LIGHT FOR IT, IT WILL HAPPILY GO TO SLEEP. A NIGHT, YOUR PET WILL BE VERY TIRED, AND JUST FALL ASLEEP RIGHT ON THE ROOR, IF YOU WANT YOUR PET TO HAVE GOOD DREAMS, TURN OUT THE LIGHT AT NIGHT, TOO.



SOMETIMES IT'S HARD TO TELL WHEN YOUR PET NEEDS TO SLEEP, IF YOU TRY EVERYTHING BLSE-- FEDING, PLAYING, OR CLEANING-- AND YOUR PET STILL SEEMS UPSET, MAYBE IT'S TIME FOR A LITTLE NAP.

PLAY
TO KEEP YOUR BARBIE PRECIOUS KITTY
HEALTHY AND HAPPY, YOU SHOULD PLAY WITH IT OFTEN.
WHEN YOU SELECT THIS ACTIVITY, YOUR PET WILL PLAY A GAME WITH YOU.

TO PLAY WITH YOUR **PRECIOUS KITTY**, WATCH FOR THE BUTTERRY AND HELP YOUR KITTY POUNCE ON IT! QUICKLY PRESS THE **LEFT** OR **RIGHT** KEY IN THE DIRECTION OF THE BUTTERRY TO POUNCE ON IT. YOUR KITTY WILL LET THE BUTTERRY GO EACH TIME, SO YOU CAN PLAY AS OFTEN AS YOU LIKE!



DOCTOR TT IF YOUR PETS HEALTH DROPS, YOU CAN ALWAYS TRY A VISIT TO THE DOCTOR. BUT BE CAREFUL! THERE'S ONLY SO MUCH THE DOCTOR CAN DO, AND YOUR PET DOES NOT LIKE TO GO. BARBIE SAYS, "ONLY ONE TRIP TO THE DOCTOR EACH DAY, MORE THAN THAT WILL MAKE VIVID DET (IMMADDAY)." YOUR PET UNHAPPY!"

CLEANING 🦪 CLEANING TO SOMETIMES YOUR PET WILL LEAVE DROPPINGS, AND YOU MUST CLEAN THEM UP. IF THERE ARE DROPPINGS ON SCREEN, SELECT CLEANING TO CLEAR THEM AWAY. IF THERE ARE NO DROPPINGS ON SCREEN, YOU CAN SELECT THIS ACTIVITY TO GIVE YOUR PET A THOROUGH, ALL OVER CLEANING. IF YOU WANT YOUR PET TO STAY HEALTHY, DON'T LEAVE DROPPINGS ON THE SCREEN, AND DON'T FORGET TO GIVE YOUR PET A BATH AT LEAST ONCE A DAY.



SCORE V CHOOSE THIS ICON TO CHECK ON YOUR PET'S PROGRESS. VOUR PETS AGE AND WEIGHT, HEALTH O
AND HAPPINESS (D., HUNGER AND
DISCIPLINE (D., AND TOTAL SCORE)

YOUR PET'S AGE INCREASES BY I EVERY DAY, WHAT SEEMS LIKE A DAY TO YOU IS ACTUALLY ONE COMPLETE YEAR TO YOUR GIGA PET! A GIGA PET REACHES ADULT AGE AT ABOUT 3 DAYS, AND OLD AGE AT I4 DAYS, A GIGA PET MORE THAN I4 DAYS OLD IS VERY OLD INDEED!

YOUR PET'S **WEIGHT** WILL VARY DEPENDING ON YOUR PET'S AGE, DIET, AND EXERCISE. TOO MANY TREATS AND TOO MUCH SLEEP WILL MAKE YOUR PET FAT AND LAZY, MAKE SURE YOUR PET GETS ENOUGH EXERCISE.

HEALTH O, NAPPINESS @, HUNGER A, AND DISCIPLINE PRINCE PROM 0 (BAD) TO 100 (GOOD) AND HELP YOU PETERMINE WHAT YOUR PET MEBS. IF ANY OF THESE FALLS BELOW 20, YOU SHOULD TAKE CARE OF YOUR

THE FINAL STATISTIC, SCORE, IS AN INDICATION OF HOW WELL YOU ARE DOING. THE HIGHER YOUR SCORE, THE BETTER YOU ARE DOING, YOUR SCORE IS AN AVERAGE OF HEALTH, HAPPIWESS, HUNGER, AND DISCIPLINE.

TRAINING YOUR PET CAN DO ALL SORTS OF INTERESTING THINGS. TRAINING YOUR PET TO PERFORM TRICKS ON COMMAND IS VERY ENTERTAINING! SEECT THE TRAIN KON AND PRESS ENTER. THE WORD REWARD WILL APPEAR, BUT DON'T REWARD YOUR PET YET! FIRST, PRESS LEFT OR RIGHT UNTIL THE WORD TRICK APPEARS, NOW PRESS ENTER AGAIN. Training **V** 

A LIST OF TRICKS WILL APPEAR, YOU CAN PRESS **LEFT** OR **RIGHT** TO SEARCH THROUGH ALL THE TRICKS YOUR PET CAN LEARN, WHEN YOU SEE THE TRICK YOU WANT TO TEACH YOUR PET, PRESS **ENTER**, YOUR PET WILL TRY ITS PEST TO DO THE TRICK YOU ASKED FOR.

IF YOUR PET POES NOT GET THE TRIKK RIGHT, TRY AGAIN! IF YOUR PET POES THE TRIKK CORRECTLY, PRESS ENTER AGAIN. THE WORD REWARD SHOUD APPEAR. PRESS ENTER AGAIN TO REWARD YOUR PET WITH A TREAT, NOW YOUR PET KNOWS THIS TRICK. CONGRATULATIONS!

IF YOU WANT YOUR PET TO PERFORM ITS TRICK AT YOUR COMMAND, SELECT THE TRAINING KON AGAIN. NOW PRESS ETHER THE LEFT OR RIGHT KEY UNTIL THE WORD TRICK APPEARS. PRESS ENTER. NOW PRESS LEFT/RIGHT UNTIL THE TRICK YOU WANT APPEARS ON THE SCREEN, AND PRESS ENTER.



DISCIPLINE
SELECT THIS ACTIVITY TO DISCIPLINE YOUR PET. YOUR
PET DOES NOT LIKE TO BE DISCIPLINE, SO YOU SHOULD
ONLY DISCIPLINE YOUR PET IF ITS DISCIPLINE
FALLS PROW 20, DON'T SELECT THIS ACTIVITY TOO OFTEN,
OR YOUR PET WILL BECOME UNHAPPY AND UNHEALTHY!

ALERT ?

WHEN THIS KON LIGHTS UP, IT MEANS YOUR PET NEEDS SOMETHING, USE THE SCORE OF ACTIVITY TO TRY TO FIGURE OUT WHAT YOUR PET NEEDS: FOOD? TIME? DISCIPLINE?



MEETING YOUR PETS NEEDS IF YOU TRY TO SELECT AN ACTIVITY THAT YOUR PET DOES NOT WANT TO DO, IT

MAY REFUSE TRY SELECTING A DIFFERENT ACTIVITY UNTIL YOU REURE OUT WHAT YOUR PET NEEDS

GAME OVER

THE GAME IS OVER WHEN YOUR PET DIES. YOUR PET CAN DIE FROM BAD HEALTH OR OLD AGE IF YOUR PET DIES FROM BAD HEALTH, YOU SHOULD RESTART THE GAME AND TRY AGAIN, TAKING CARE TO PAY CLOSE ATTENTION TO YOUR PET'S NEEDS.

YOUR PET CAN ALSO DIE FROM OLD AGE. YOUR PET IS VOUR PET CAN ALSO DIE HROM OUD AGE, YOUR PET IS DESIGNED TO LIVE FOR ABOUT 2 WEEKS, HOWEVER, IF YOU TAKE VERY GOOD CARE OF YOUR PET, IT MAY LIVE LONGER, KEEP YOUR PET'S HEALTH ABOVE 73 AND IT MAY LIVE INDEPINITELY.

120

WHEN THE GAME IS OVER, YOU WILL SEE YOUR PET TURN INTO AN ANGEL, YOU CAN PRESS MODE TO SEE YOUR FINAL SCORE, AND PRESS MODE AGAIN

RESTARTING THE GAME
IF YOUR PET DIES AND BECOMES AN ANGE, PRESS ENTER
TO RESTART THE GAME IF YOU JUST WISH TO START
OVER FROM THE PEGINNING, PRESS THE RESET BUTTON LOCATED ON THE BACK OF YOUR GAME

INSERTING THE BATTERIES
TO ACTIVATE YOUR GIGA PETS GAME, PULL THE PLASTIC THE FROM
BACK OF GAME.

TO INSERT THE BATTERIES, REMOVE THE BATTERY COMPARTMENT COVER AT THE BACK OF THE GAME. (TO REMOVE COVER, UNSCREW THE COVER, THEN PUSH THE COVER IN THE PIRECTION OF THE ARROW).

INSERT TWO LOV "LR44" OR "GISA" BUTTON CELL BATTERIES (BATTERY INCLUDED), MAKING SURE TO ALIGN "" AND "-" AS SHOWN.

CAUTICON: BATTERY SHOULD BE REPLACED BY ABULT. HOT SUITABLE FOR CHILDREN UNDER 30 MONTHS, MAY CONTAIN SMALL PARTS.

NOT SUITABLE FOR CHILDREN UNDER 3D MONTHS, MAY CONTAIN SAMAL PARTS.

TO BAY SUBJE PRODUCE FUNCTIONS:

- PO NOT MAX OUR AND MAY BATTERIES.
- PO NOT MAX OUR AND MAY BATTERIES.
- PO NOT MAX OUR AND MAY BATTERIES.
- PATTERY INSTALLATION SHOULD BE DONE BY ADULT.
- NON-RECHARCEARLE BATTERIES ARE NOT TO BECKHARGED.
- RECHARCEARLE BATTERIES ARE NOT TO BE CHARGED UNDER ADULT SUPERVISION (IF REMOVEMBLE).
- RECHARCEARLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION (IF REMOVEMBLE).
- CHARGE ARE TO BE SAME OR COUNMAINT TYPE AS RECOMMENDED ARE TO BE USED.
- BATTERIES ARE TO BE INSKRITED WITH THE CORRECT POLARTY.
- ENAUGHTE BATTERIES ARE NOT TO BE SHORT—CORN. THE TOY.
- THE SUPPLY TERMINALS ARE NOT TO BE SHORT—CRECKITED.

DEFECT OR DAMAGE.

IF A PART OF YOUR GAME IS DAMAGED OR SOMETHING HAS BEEN LIST OUT, DO NOT RETURN THE GAME TO THE STORE THE STORE DESIRT HAVE REPLACEMENT PART.

INSTEAD, WRITE TO US AT:

TIGER ELECTRONIC TOYS REPAIR CENTRE
190 WOODLANDS PARKWAY, VERNON HILLS,
RLINGIS BOOD, U.S.A.

In your note, mention the name of your game, your games morel number, and tell us preply what the proplem is, also include sales sup; pate, place of purchase and price paid. We will do our best to help:

## 90-day limited warranty

TIGER ELECTRONICS, INC. (TIGER) WARRANTS TO THE ORIGINAL CONSUMER PURCHASER OF THIS PRODUCT THAT THE PRODUCT WILL BE FREE FROM DEFECTS IN MATERIALS OR WORKMANSHIP FOR 70 DAYS FROM THE DATE OF ORIGINAL PURCHASE. THIS WARRANTY DOES NOT COVER PAMAGES RESULTING FROM ACCIDENT, NEGLIGENCE, IMPROPER SERVICE OR USE OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIALS OR WORKMANSHIP.

puring this 70-pay warranty period, the product will either be repaired or replaced (at tiger's option) without charge to the purchaser, when returned with proof of the pate of purchase to EITHER THE DEALER OR TO TIGER.

PRODUCT RETURNED TO TIGER WITHOUT PROOF OF THE DATE OF PURCHASE OR AFTER THE 70-DAY WARRANTY PERIOD HAS EXPIRED, BUT PRIOR TO ONE YEAR FROM THE ORIGINAL DATE OF PURCHASE, WILL BE REPAIRED OR REPLACED (AT TIGER'S OPTION) FOR A STRYKE FEE OF US?4.00. PAYMENTS MUST BE BY CHECK OR MONEY ORDER PAYABLE TO TIGER ELECTRONICS, INC

THE FOREGOING STATES THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY WITH RESPECT TO THE PROPUCT.

ALL PRODUCT RETURNED MUST BE SHIPPED PREPAID AND INSURED FOR LOSS OR DAMAGE TO:

TIGER ELECTRONICS, INC. REPAIR DEPT. 780 WOODLANDS PARKWAY VERNON HILLS, ILLINOIS BOODL

THE PRODUCT SHOULD BE CAREFULLY PACKED IN THE ORIGINAL BOX OR OTHER PACKING MATERIALS SUFFICIENT TO AVOID DAMAGE DURING SHIPMENT, INCLUDE A COMPLETE WRITTEN DESCRIPTION OF THE DEFECT, A CHECK IF PRODUCT IS BEYOND THE 70-DAY WARRANTY PERIOD, AND YOUR PRINTED NAME, APDRESS AND TELEPHONE NUMBER.

AND TELEPHONE NUMBER.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE TIGER IN ANY WAY. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE NUMETY (70) DAY PERIOD DESCRIBED ABOVE. IN NO EVENT WILL TIGER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE, OR MALFUNCTION OF THIS TIGER PRODUCT.

SOME STATES PO NOT ALLOW LIMITATIONS AS TO HOW LONG AN IMPLIED WARRANTY LASTS AND/OR EXCLUSIONS OR LIMITATIONS OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND/OR EXCLUSIONS OF LIABILITY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE

BARBIE is a trademark owned by and used under license from Mattel, Inc. © 1997 Mattel, Inc. All Rights Reserved.